

Recofloor specifications

- Ensure the correct usage of the container for the vinyl type you are collecting. That is for example, for smooth vinyl offcuts, use the smooth vinyl offcuts bag. We accept:
 - Smooth sheet vinyl offcuts, roll-ends or uplifted flooring with a clean top surface and less than 3mm of screed or adhesive. No cushion or felt backed vinyl.
 - Safety sheet vinyl flooring offcuts or roll-ends.
 - Luxury vinyl tiles (LVT), including wood plank style offcuts.
 - Loose lay sheet, roll-ends or plank style offcuts or uplifted vinyl.
 - Altro and/or Polyflor welding rods.

When working with multiple vinyl flooring types, please contact us for advice.

- Ensure containers are kept on solid ground and accessible for collection.
- Inform us of any site restrictions in relation to vehicle heights, security arrangements, site opening hours etc.
- Keep containers within fill capacity level and ensure the material is adequately contained within the container. For bins, please keep lids locked.
- Source and securely place Recofloor bulk bags on standard pallets (1200mm x 1000mm) to allow for easy movement with a forklift or pallet truck. Tie the bag loops when full.
- Bins need to be returned prior to the end of the participation within the scheme. Where bins are provided, to keep them serviceable, please:
 - Do not paint or write on them or add any personal stickers.
 - Use the wheel brakes to ensure they don't move around the site.
 - Remember to release the brakes before moving or loading the bin onto a vehicle to prevent wheel buckling.
 - Take general care of the bins and try not to dent them.
- Roll-ends should be palletised using a 2m wide pallet or 2 standard pallets strapped together. They should then be placed on the pallets in a pyramid formation and secured using banded cord strap.

